



CGH Toy Line FAQs

Q: What is the best way to care for the Styling Heads and the Styling Wig & Display?

A: There are several ways to care for your CGH Styling Heads and Styling Wig & Display, including:

- Combing hair carefully from bottom to top in sections to avoid tangling
- Use a spray bottle of room temperature water to flatten hair
- Only comb hair when completely dry
- NEVER use heated tools on hair

Q: Why do some strands of hair fall out during play?

A: Small amounts of hair loss during play is normal. In order to limit the amount of hair that falls out make sure to follow the included hair care and combing instructions.

Q: Can I wash the hair on the styling heads and wigs?

A: Hand wash only in warm water with mild shampoo. NEVER use washer/dryer. Handle gently and rinse completely.

Q: Can I use conditioner on the styling heads and wigs?

A: Yes, but only if it is mild. Handle gently and rinse completely.

Q: How do I dry the hair?

A: Pat the hair until dry to remove excess water. Hang to dry. NEVER use a blow dryer or heating products on the hair. Only comb and style the hair when it is completely dry. NEVER comb when the hair is wet.

Q: Can I iron or curl the hair?

A: No. Heat will damage the hair.

Q: Can I dye the hair?

A: No. Dying the hair will damage it.

Q: Can I use hairstyling products in the hair?

A: Not recommended, but if hairspray, gel or other styling products are used, the hair should be cleaned using the care instructions noted above.

Q: Can I apply makeup to the face?

A: No, it is not recommended to apply makeup to the face.

Q: How do I clean the face?

A: Use a clean damp cloth.



CGH Toy Line FAQs

Q: What is the hair made of?

A: Nylon

Q: How do I use the clamp?

A: The clamp is intended to be used to help stabilize the styling heads and/or the styling wig & display wig form. This makes it easier to style the hair. You can watch the “how to” video on www.jakks.com/cutegirlshairstyles

Q: How do I attach the clamp?

A: The clamp can be easily connected to a table. An adult can help with this. You can also refer to the instruction sheet or watch the “how to” video on www.jakks.com/cutegirlshairstyles

Q: How do I attach the styling head and/or Styling Wigs & Displays to the clamp?

A: The head and/or styling wig & display can be easily connected to the clamp. Simply place the head/styling wig & display on top of the clamp and slide down. An adult can help with this. You can also watch the “how to” video on www.jakks.com/cutegirlshairstyles

Q: How do I assemble the Styling Wig & Display?

A: The Styling Wig & Display a one-time assembly. First apply one side to the neck and then apply the second side. It will take a little bit of force so ask an adult for help. You can also watch the “how to” video on www.jakks.com/cutegirlshairstyles

Q: How do I attach the wig to the Styling Wig Display?

A: There are 9 hooks in total, with 5 in the front, 1 on the top and 3 in the back. Carefully take each loop on the wig and attach to the hooks on the head in numerical order. You can refer to the instruction sheet on how to do this and also watch the “how to” video on www.jakks.com/cutegirlshairstyles. An adult can help with this.

Q: Are the hair accessories like the Mermaid Kit, Cat Ears Kit, Unicorn Kit, Crochet Hair Kit, and Hair Jewel Kit intended for use on girls’ hair or for use on the styling heads and wigs?

A: The accessories are meant for both! You can practice using the styling accessories on your styling heads and wigs and you can also use them on your own hair!

Q: Can I use the Glitter Brush on my own hair?

A: Yes! It is fully-tested and safe for use on your hair. To remove it from you hair, simply wash your hair as you normally do!

Q: Can I use the Glitter Brush on the styling heads and wigs?

A: Yes. When you are ready to remove the glitter, Hand wash only in warm water with mild shampoo. NEVER use washer/dryer. Handle gently and rinse completely.